


MonnitLink™ USB Driver - Manual Installation Instructions for Windows XP


Unzip the contents of the driver zip file to a location that you can easily access. Within that folder, double click on the self installing application 'DPInst-x64.exe' (64-bit) or 'DPInst-x86.exe' (32-bit) and follow the on-screen instructions.

In the event the executable is unable to complete the installation process, follow these steps to manually install the MonnitLink™ USB driver.


1. Open device manager (start menu, right click my computer, choose properties, choose hardware tab, click device manager button.)
2. Insert the MonnitLink™ USB into an empty USB port on your computer.
3. Right click 'M+ Link' and choose 'Update Driver'.




4. Choose 'No, not this time' and click 'Next'.



5. Choose 'Install from a specific location', then click 'Next'.




6. Choose 'Don't search I will choose the driver to install' and click 'Next'.




7. Click 'Have Disk'.

8. Click on the 'Browse' button and select the folder where you unzipped the driver files, then click 'OK'.


9. Choose 'Monnit USB Radio Gateway' and click 'Next'.




10. Wait for the installation to complete.



11. Click 'Finish'.



12. In the Device Manager you will now see 'Monnit USB Radio Gateway'.



13. Congratulations you've manually installed the Monnit USB Radio Gateway Driver. You can now close the installation window and begin using your Monnit Wireless Sensor System.